


# Chemistry 4631

## Instrumental Analysis

### Lecture 20




© 2007 Thomson Higher Education

# Potentiometry

Measures potential under very low currents.

The cell is 2 half cells. Consist of a reference electrode, indicator electrode, and potential measuring device.



# Potentiometry

## Reference electrodes

**An electrode with a known constant half-potential and insensitive to composition of the solution.**

## Ideal reference

- **Reversible and obeys Nernst Law**
- **Exhibits stable potential over time**
- **Returns to original potential in presence of small currents**
- **Not sensitive to temperature changes**

# Potentiometry

**TABLE 23-1** Potentials of Reference Electrodes in Aqueous Solutions

Temperature, °C	Electrode Potential vs. SHE, V				
	0.1 M <sup>c</sup> Calomel <sup>a</sup>	3.5 M <sup>c</sup> Calomel <sup>b</sup>	Saturated <sup>c</sup> Calomel <sup>a</sup>	3.5 M <sup>b,c</sup> Ag-AgCl	Saturated <sup>b,c</sup> Ag-AgCl
10	—	0.256	—	0.215	0.214
12	0.3362	—	0.2528	—	—
15	0.3362	0.254	0.2511	0.212	0.209
20	0.3359	0.252	0.2479	0.208	0.204
25	0.3356	0.250	0.2444	0.205	0.199
30	0.3351	0.248	0.2411	0.201	0.194
35	0.3344	0.246	0.2376	0.197	0.189
38	0.3338	—	0.2355	—	0.184
40	—	0.244	—	0.193	—

© 2007 Thomson Higher Education

# Potentiometry

## Reference Electrodes

### Calomel Electrodes (SCE)

Consist of Hg in contact with solution of calomel and KCl.

Hg | Hg<sub>2</sub>Cl<sub>2</sub> (saturated), KCl (xM) ||

KCl usually 0.1, 1 M, and 4.6 ← saturated SCE

SCE most commonly used reference electrode


Advantage -- easy to prepare

Disadvantage -- sensitive to temperature changes

$E^0_{\text{SCE}} = 0.244\text{V}$  at 25°C

Electrode reaction:  $\text{Hg}_2\text{Cl}_2 (\text{s}) + 2\text{e}^- \rightleftharpoons 2\text{Hg} (\text{l}) + 2\text{Cl}^- (\text{aq})$

# Calomel Electrode



# Potentiometry

## Reference Electrodes

### Ag/AgCl Electrodes

Ag wire in solution of KCl and AgCl


Ag | AgCl (saturated), KCl (saturated) ||



$$E^0_{\text{Ag/AgCl}} = 0.199\text{V at } 25^\circ\text{C}$$

# Ag/AgCl Electrodes

saturated AgCl/KCl



# Potentiometry

## Indicator Electrodes

**An electrode system having a potential that varies in a known way with variations in the concentration of an analyte.**

$$E_{\text{cell}} = E_{\text{ind}} - E_{\text{ref}} + E_j$$

## Ideal Indicator Electrode

- Responds quickly to concentration change of an analyte.**
- Gives reproducible results.**

# Potentiometry

## Indicator Electrodes

### Three type of indicator electrodes

- **Metallic**
- **Membrane**
- **Ion-selective**

# Potentiometry

## Indicator Electrodes

### Metallic Indicator Electrodes

#### Redox system

Pt, Pd, Au or C in contact with redox system.

i.e. Pt in  $\text{Ce}^{\text{III}}/\text{Ce}^{\text{IV}}$

$$E_{ind} = E^{\circ}_{\text{Ce(IV)}} - 0.0592 \log \frac{a_{\text{Ce}^{+3}}}{a_{\text{Ce}^{+4}}}$$

# Potentiometry

## Membrane Indicator Electrodes

Membrane Electrodes also called ion selective electrodes (ISEs) or pIon electrodes

**TABLE 23-2** Types of Ion-Selective Membrane Electrodes

- |  |
|--|
| <p>A. Crystalline Membrane Electrodes</p> <ol style="list-style-type: none"><li>1. Single crystal<br/>Example: <math>\text{LaF}_3</math> for <math>\text{F}^-</math></li><li>2. Polycrystalline or mixed crystal<br/>Example: <math>\text{Ag}_2\text{S}</math> for <math>\text{S}^{2-}</math> and <math>\text{Ag}^+</math></li></ol> <p>B. Noncrystalline Membrane Electrodes</p> <ol style="list-style-type: none"><li>1. Glass<br/>Examples: silicate glasses for <math>\text{Na}^+</math> and <math>\text{H}^+</math></li><li>2. Liquid<br/>Examples: liquid ion exchangers for <math>\text{Ca}^{2+}</math> and neutral carriers for <math>\text{K}^+</math></li><li>3. Immobilized liquid in a rigid polymer<br/>Examples: PVC matrix for <math>\text{Ca}^{2+}</math> and <math>\text{NO}_3^-</math></li></ol> |
|--|

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

#### Properties

- **Minimal Solubility** – solubility in analyte solutions approaches zero
- **Electrical Conductivity** – must be small usually in the form of migration of singly charged ions within the membrane
- **Selective Reactivity** – must selectively bind with analyte ion by ion-exchange, crystallization, or complexation

# Potentiometry

## Indicator Electrodes

Membrane Electrodes

pION electrodes

i.e. pH Electrode -- glass electrode

No electrons transported across membrane

Membrane allows certain ion to cross while excluding others.

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

**pH Electrode -- glass electrode**

**Responds to changes in pH**

**Consist of**


- a sensing electrode
- reference electrode (half-cell system)

**Nowdays use a combination electrode**

- a sensing electrode with a built in reference.

# Potentiometry

## pH Electrode



- A - pH sensor
- B - reference half cell
- C - combination pH electrode (A+B)
- D- seal
- E- internal filling solution
- F- internal reference electrode
- G- external filling solution
- H- pH sensitive glass membrane
- I- internal liquid junction
- J- external liquid junction
- K- fill hole

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

**pH Electrode -- glass electrode**

**The sensing electrode measures pH across the thin glass membrane**


- **0.03 to 1.00 mm thick**
- **consist of 22%  $\text{Na}_2\text{O}$ , 6%  $\text{CaO}$ , 72%  $\text{SiO}_2$**
- **or 10%  $\text{Li}_2\text{O}$ , 10%  $\text{CaO}$ , and 80%  $\text{SiO}_2$  (for  $\text{Na}^+$  error)**

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

### pH Electrode -- glass electrode




# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

#### pH Electrode -- glass electrode

pH measurement occurs by an ion-exchange reaction:



# Potentiometry


## pH Electrode -- glass electrode

### Membrane electrodes

$\text{H}_3\text{O}^+$  partially populates both the inner and outer  $\text{SiO}_2$  surfaces.

The concentration difference results in a potential across the glass membrane.

A special glass is used:  
22%  $\text{Na}_2\text{O}$ , 6%  $\text{CaO}$ , 72%  $\text{SiO}_2$



# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

Membrane electrodes can also be used to measure other ions.

1<sup>st</sup> type that were used:  $\text{Na}^+$ ,  $\text{Ca}^{2+}$ , and  $\text{Cl}^-$

( $\text{Na}^+$  selective glass electrode made up of 11%  $\text{Na}_2\text{O}$ , 18%  $\text{Al}_2\text{O}_3$ , 71%  $\text{SiO}_2$ )

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

Instead of glass the membrane may be a polymer saturated with a liquid ion exchanger (with ion-exchange capabilities).

Ion selective electrodes - ISE's

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes


Many ISE's (and pH electrodes) are membrane-based devices which separate the sample from the inside of the electrode. On the inside is a filling solution containing the ion of interest at a constant activity.

# Potentiometry

## Ca ion selective electrode example

### Liquid membrane electrodes

**Ca<sup>2+</sup> electrode**




# Potentiometry

## Ca ion selective electrode example

### Liquid membrane electrodes

The reservoir forces exchanger into the membrane.  
The exchanger forms complexes with the species of interest.

The results in a concentration difference and a resulting  $\Delta V$  that we can measure.



# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

A gradient is established across the membrane when the electrode is immersed in a solution.

$$\Delta G = -RT \ln(a_{\text{sample}}/a_{\text{int.soln.}}) \quad R = 8.134 \text{ J/K mol}$$

Potential produced:

$$E = -\Delta G/nF = (RT/nF) \ln(a_{\text{sample}}/a_{\text{int.soln.}})$$

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

Potential produced:

$$E = -\Delta G/nF = (RT/nF) \ln(a_{\text{sample}}/a_{\text{int.soln.}})$$

This potential is monitored relative to a reference electrode.

$E_{\text{ref}}$  - constant (fixed)

$a_{\text{int. soln.}}$  - constant

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

$$E = K + (2.303RT/Z_i F) \log a_i \quad \text{where,}$$

$Z_i$  - ionic charge

$a_i$  - ionic activity

$K$  - constant

# Potentiometry

## Indicator Electrodes

### Membrane Electrodes

**E is proportional to  $\log a_i$**

- so a **59.1 mV** change corresponds to a **10 fold change** in **a** (for monoatomic ions)
- **$a_i$  - unity for dilute solutions**
- to relate E to [ ] need to use standardization curves.

# Potentiometry

**TABLE 23-4** Characteristics of Liquid-Membrane Electrodes

Analyte Ion	Concentration Range, M <sup>†</sup>	Major Interferences <sup>‡</sup>
NH <sub>4</sub> <sup>+</sup>	10 <sup>0</sup> to 5 × 10 <sup>-7</sup>	<1 H <sup>+</sup> , 5 × 10 <sup>-1</sup> Li <sup>+</sup> , 8 × 10 <sup>-2</sup> Na <sup>+</sup> , 6 × 10 <sup>-4</sup> K <sup>+</sup> , 5 × 10 <sup>-2</sup> Cs <sup>+</sup> , >1 Mg <sup>2+</sup> , >1 Ca <sup>2+</sup> , >1 Sr <sup>2+</sup> , >0.5 Sr <sup>2+</sup> , 1 × 10 <sup>-2</sup> Zn <sup>2+</sup>
Cd <sup>2+</sup>	10 <sup>0</sup> to 5 × 10 <sup>-7</sup>	Hg <sup>2+</sup> and Ag <sup>+</sup> (poisons electrode at >10 <sup>-7</sup> M), Fe <sup>3+</sup> (at >0.1[Cd <sup>2+</sup> ]), Pb <sup>2+</sup> (at >[Cd <sup>2+</sup> ]), Cu <sup>2+</sup> (possible)
Ca <sup>2+</sup>	10 <sup>0</sup> to 5 × 10 <sup>-7</sup>	10 <sup>-5</sup> Pb <sup>2+</sup> ; 4 × 10 <sup>-3</sup> Hg <sup>2+</sup> , H <sup>+</sup> , 6 × 10 <sup>-3</sup> Sr <sup>2+</sup> ; 2 × 10 <sup>-2</sup> Fe <sup>2+</sup> ; 4 × 10 <sup>-2</sup> Cu <sup>2+</sup> ; 5 × 10 <sup>-2</sup> Ni <sup>2+</sup> ; 0.2 NH <sub>3</sub> ; 0.2 Na <sup>+</sup> ; 0.3 Tris <sup>+</sup> ; 0.3 Li <sup>+</sup> ; 0.4 K <sup>+</sup> ; 0.7 Ba <sup>2+</sup> ; 1.0 Zn <sup>2+</sup> ; 1.0 Mg <sup>2+</sup>
Cl <sup>-</sup>	10 <sup>0</sup> to 5 × 10 <sup>-6</sup>	Maximum allowable ratio of interferent to [Cl <sup>-</sup> ]: OH <sup>-</sup> 80, Br <sup>-</sup> 3 × 10 <sup>-3</sup> , I <sup>-</sup> 5 × 10 <sup>-7</sup> , S <sup>2-</sup> 10 <sup>-6</sup> , CN <sup>-</sup> 2 × 10 <sup>-7</sup> , NH <sub>3</sub> 0.12, S <sub>2</sub> O <sub>3</sub> <sup>2-</sup> 0.01
BF <sub>4</sub> <sup>-</sup>	10 <sup>0</sup> to 7 × 10 <sup>-6</sup>	5 × 10 <sup>-7</sup> ClO <sub>4</sub> <sup>-</sup> ; 5 × 10 <sup>-6</sup> I <sup>-</sup> ; 5 × 10 <sup>-5</sup> ClO <sub>3</sub> <sup>-</sup> ; 5 × 10 <sup>-4</sup> CN <sup>-</sup> ; 10 <sup>-3</sup> Br <sup>-</sup> ; 10 <sup>-3</sup> NO <sub>2</sub> <sup>-</sup> ; 5 × 10 <sup>-3</sup> NO <sub>3</sub> <sup>-</sup> ; 3 × 10 <sup>-3</sup> HCO <sub>3</sub> <sup>-</sup> ; 5 × 10 <sup>-2</sup> Cl <sup>-</sup> ; 8 × 10 <sup>-2</sup> H <sub>2</sub> PO <sub>4</sub> <sup>-</sup> ; HPO <sub>4</sub> <sup>2-</sup> ; PO <sub>4</sub> <sup>3-</sup> ; 0.2 OAc <sup>-</sup> ; 0.6 F <sup>-</sup> ; 1.0 SO <sub>4</sub> <sup>2-</sup>
NO <sub>3</sub> <sup>-</sup>	10 <sup>0</sup> to 7 × 10 <sup>-6</sup>	10 <sup>-7</sup> ClO <sub>4</sub> <sup>-</sup> ; 5 × 10 <sup>-6</sup> I <sup>-</sup> ; 5 × 10 <sup>-5</sup> ClO <sub>3</sub> <sup>-</sup> ; 10 <sup>-4</sup> CN <sup>-</sup> ; 7 × 10 <sup>-4</sup> Br <sup>-</sup> ; 10 <sup>-3</sup> HS <sup>-</sup> ; 10 <sup>-2</sup> HCO <sub>3</sub> <sup>-</sup> ; 2 × 10 <sup>-2</sup> CO <sub>3</sub> <sup>2-</sup> ; 3 × 10 <sup>-2</sup> Cl <sup>-</sup> ; 5 × 10 <sup>-2</sup> H <sub>2</sub> PO <sub>4</sub> <sup>-</sup> ; HPO <sub>4</sub> <sup>2-</sup> ; PO <sub>4</sub> <sup>3-</sup> ; 0.2 OAc <sup>-</sup> ; 0.6 F <sup>-</sup> ; 1.0 SO <sub>4</sub> <sup>2-</sup>
NO <sub>2</sub> <sup>-</sup>	1.4 × 10 <sup>-6</sup> to 3.6 × 10 <sup>-6</sup>	7 × 10 <sup>-1</sup> salicylate, 2 × 10 <sup>-3</sup> I <sup>-</sup> , 10 <sup>-1</sup> Br <sup>-</sup> , 3 × 10 <sup>-1</sup> ClO <sub>3</sub> <sup>-</sup> , 2 × 10 <sup>-1</sup> acetate, 2 × 10 <sup>-1</sup> HCO <sub>3</sub> <sup>-</sup> , 2 × 10 <sup>-1</sup> NO <sub>3</sub> <sup>-</sup> , 2 × 10 <sup>-1</sup> SO <sub>4</sub> <sup>2-</sup> , 1 × 10 <sup>-1</sup> Cl <sup>-</sup> , 1 × 10 <sup>-1</sup> ClO <sub>4</sub> <sup>-</sup> , 1 × 10 <sup>-1</sup> F <sup>-</sup>
ClO <sub>4</sub> <sup>-</sup>	10 <sup>0</sup> to 7 × 10 <sup>-6</sup>	2 × 10 <sup>-3</sup> I <sup>-</sup> ; 2 × 10 <sup>-2</sup> ClO <sub>3</sub> <sup>-</sup> ; 4 × 10 <sup>-2</sup> CN <sup>-</sup> , Br <sup>-</sup> ; 5 × 10 <sup>-2</sup> NO <sub>2</sub> <sup>-</sup> , NO <sub>3</sub> <sup>-</sup> ; 2 HCO <sub>3</sub> <sup>-</sup> , CO <sub>3</sub> <sup>2-</sup> ; Cl <sup>-</sup> , H <sub>2</sub> PO <sub>4</sub> <sup>-</sup> , HPO <sub>4</sub> <sup>2-</sup> , PO <sub>4</sub> <sup>3-</sup> , OAc <sup>-</sup> , F <sup>-</sup> , SO <sub>4</sub> <sup>2-</sup>
K <sup>+</sup>	10 <sup>0</sup> to 1 × 10 <sup>-6</sup>	3 × 10 <sup>-4</sup> Cs <sup>+</sup> ; 6 × 10 <sup>-3</sup> NH <sub>4</sub> <sup>+</sup> , Tl <sup>+</sup> ; 10 <sup>-2</sup> H <sup>+</sup> ; 1.0 Ag <sup>+</sup> , Tris <sup>+</sup> ; 2.0 Li <sup>+</sup> , Na <sup>+</sup>
Water hardness (Ca <sup>2+</sup> + Mg <sup>2+</sup> )	10 <sup>-3</sup> to 6 × 10 <sup>-6</sup>	3 × 10 <sup>-5</sup> Cu <sup>2+</sup> , Zn <sup>2+</sup> ; 10 <sup>-4</sup> Ni <sup>2+</sup> ; 4 × 10 <sup>-4</sup> Sr <sup>2+</sup> ; 6 × 10 <sup>-5</sup> Fe <sup>2+</sup> ; 6 × 10 <sup>-4</sup> Ba <sup>2+</sup> ; 3 × 10 <sup>-2</sup> Na <sup>+</sup> ; 0.1 K <sup>+</sup>

All electrodes are the plastic-membrane type.

# Potentiometry

## Indicator Electrodes

### Solid State Electrodes

Eventually membrane electrodes (ISE's) lead to solid-state electrodes

**TABLE 23-3** Characteristics of Solid-State Crystalline Electrodes

Analyte Ion	Concentration Range, M	Major Interferences
Br <sup>-</sup>	10 <sup>0</sup> to 5 × 10 <sup>-6</sup>	CN <sup>-</sup> , I <sup>-</sup> , S <sup>2-</sup>
Cd <sup>2+</sup>	10 <sup>-1</sup> to 1 × 10 <sup>-7</sup>	Fe <sup>2+</sup> , Pb <sup>2+</sup> , Hg <sup>2+</sup> , Ag <sup>+</sup> , Cu <sup>2+</sup>
Cl <sup>-</sup>	10 <sup>0</sup> to 5 × 10 <sup>-5</sup>	CN <sup>-</sup> , I <sup>-</sup> , Br <sup>-</sup> , S <sup>2-</sup> , OH <sup>-</sup> , NH <sub>3</sub>
Cu <sup>2+</sup>	10 <sup>-1</sup> to 1 × 10 <sup>-8</sup>	Hg <sup>2+</sup> , Ag <sup>+</sup> , Cd <sup>2+</sup>
CN <sup>-</sup>	10 <sup>-2</sup> to 1 × 10 <sup>-6</sup>	S <sup>2-</sup> , I <sup>-</sup>
F <sup>-</sup>	Sat'd to 1 × 10 <sup>-6</sup>	OH <sup>-</sup>
I <sup>-</sup>	10 <sup>0</sup> to 5 × 10 <sup>-8</sup>	CN <sup>-</sup>
Pb <sup>2+</sup>	10 <sup>-1</sup> to 1 × 10 <sup>-6</sup>	Hg <sup>2+</sup> , Ag <sup>+</sup> , Cu <sup>2+</sup>
Ag <sup>+</sup> /S <sup>2-</sup>	Ag <sup>+</sup> : 10 <sup>0</sup> to 1 × 10 <sup>-7</sup> S <sup>2-</sup> : 10 <sup>0</sup> to 1 × 10 <sup>-7</sup>	Hg <sup>2+</sup>
SCN <sup>-</sup>	10 <sup>0</sup> to 5 × 10 <sup>-6</sup>	I <sup>-</sup> , Br <sup>-</sup> , CN <sup>-</sup> , S <sup>2-</sup>

# Potentiometry

## Indicator Electrodes

### Solid State Electrodes

#### Crystal electrodes

#### Example - fluoride ion-selective electrode

#### Consist of :

- $\text{LaF}_3$  crystal
- Internal electrolyte solution (0.1 M NaF and 0.1 M KCl)
- Ag/AgCl wire



# Potentiometry

## Indicator Electrodes

### Solid State Electrodes

#### Crystal electrodes

Example - fluoride ion-selective electrode

$\text{LaF}_3$  crystal is doped with  $\text{EuF}_2$  to provide vacancies (holes) of a fluoride ion site.

Nerstian response is obtained down to  $10^{-6}\text{M}$

$$E = K - 0.0591 \log a_{\text{F}^-}$$

Interference ( $\text{OH}^-$ ) - has a similar size and charge, so the pH range for the electrode is only 0 to 8.5

# Potentiometry

## Indicator Electrodes

### Solid State Electrodes


#### ISFET - ion selective field effect transistor

- Coat a transistor with a chemically sensitive material
- Analyte in contact with material and reference electrode
- Change in analyte concentration give a change in electrochemical potential

Advantages - rugged, small, inert, rapid response

Disadvantage – must have a reference electrode

# Potentiometry



© 2007 Thomson Higher Education

# Assignment

- Read Chapter 22
- HW11 Chapter 22: 1, 5, 7, 9, and 11
- HW11 Due 3/22/24
  
- Read Chapter 23
- HW12 Chapter 23: 2, 4, 7, 8, and 11
- HW12 Chapter 23 Due 3/29/24

